


Technical detail (dimensions are in mm)



*NB: If the projection is over 560mm and below 1000mm then the maximum width is 2000mm




Fixing detail

Canopy should be stored in its packaging on its back with the rear of the up-stand facing downwards.

GRP canopies are light in relation to their size and in most cases can be handled manually, care should be taken not to damage the canopy whilst handling/manoeuvring. Please refer to manual handling REG's 1992 and HSE guidance sheets prior to starting installation of your door canopy.

Installation

1. Measure and fix the locator brackets at the required height using the M8 anchor bolts
2. Locate the canopy onto the locator brackets
3. Check the canopy is sitting level, fix the canopy through the up-stand using hammer fixings at approx 225mm centres* (finish with colour coded caps)
4. Seal using a proprietary all weather silicone sealant, avoid sealing the soffit to the wall




Fixing kit

*The fixing points shown are a guide for the hammer fixings.



Hammer fixings x 3
(+1 for every extra 225mm)



Locator bracket x 2
(+1 for every extra 1000mm)



M8 Anchor bolt x 2
(+1 for every extra 1000mm)



Colour coded caps x 3
(+1 for every extra Hammer fixing)

Royale variable

Scale: Not to scale

canopies uk
www.canopiesuk.co.uk